



# Installation Instructions

## Before installing your top, you will need the following items:

- Level
- Silicone (Note: We recommend using high quality silicones. Silicone colour options may include white, bone or clear)
- Silicone gun
- Paper towel
- Popsicle stick
- Utility knife

## Installing a cultured marble top

- Make sure that cabinet is level and free of debris.
- Place top onto cabinet and check to see that the cabinet is level and that all overhangs are correct.
- Install taps
- Install drainage: Apply a small amount of silicone around the drainage hole and then place fixture on it.

### **Important Precautions:**

Do not use plumbers putty around the drainage as it may damage the top.

Tighten the drainage fixture (Do not over-tighten as this may cause damage).

- If you have ordered a sidesplash, wipe it down with a paper towel and on the back side apply two quarter size dabs of silicone, evenly spaced, then adhere to wall.
- Wipe down all areas that need to be siliconed (ie. Marble to wall and marble to marble).
- Apply a bead of silicone on the edge of the marble top where it comes in contact with the wall (Note: In order to make future vanity top replacement easy, do not silicone the bottom of the vanity top onto the cabinet or the backside of the backsplash on to the wall).
- Apply a bead of silicone on the edge of the sidesplash where it comes in contact with wall and the vanity top.
- Remove excess with a Popsicle stick and then smooth out by wetting the bottom of your finger and lightly running it along the length of the silicone bead.

## **Manufacturers of Cultured Marble, Onyx & Granite Bathware Toptech Solid Surface Products**

4250 – 80<sup>th</sup> Ave. S.E., Calgary, Alberta T2C 3A2 Phone: (403) 279-2552 Fax: (403) 279-4302